

KeraLite® XL Crate Information

Take care of the glass



When handling EuroKera glass-ceramic, please be sure to follow these **safe** and **efficient** crate* handling techniques and recommendations.


Features

Weight

- Out of charge: 155 kg
- With sheets: 1501.4 kg

Sheets

- 2000 x 1100 mm (usable width)
- 4 or 5 mm thickness
- 50 sheets of 4 mm per crate
- 40 sheets of 5 mm per crate



Sheets are already tilted inside the box

Handling Precautions

External



Internal



Forbidden (except for truck loading/unloading)



Stacking on 1 level maximum



The 2 horizontal wood bars must be set up before any crate moving**





* Crates are in accordance with the ISPM No.15 standard

** See image 5 on reverse

Recommendations

The following steps are recommended prior to unloading sheets from the XL crate.

- ① Unscrew **the top**
(**7 screws** identified
by **red marks**)
- ② **Remove** the top
- ③ Unscrew **the frontage**
(9 screws)
- ④ **Remove** the frontage
- ⑤ **Unscrew and remove** the
2 horizontal wood bars



eurokera

EuroKera

7 Avenue de Tivoli,
02400 Chierry, France

eurokera.com

KeraLite®